



4.5" DOWNLIGHT CYLINDER

SURFACE MOUNT




COMPONENTS


STANDARD CANOPY



CONDUIT FEED CANOPY















4" OCTAGONAL J-BOX REQUIRED FOR INSTALLATION




JUNCTION BOX (BY OTHERS)

INSTRUCTION KEY	INFORMATION
⚠ ADDITIONAL	INSTALLATION SHOULD ONLY BE PERFORMED BY A CERTIFIED ELECTRICIAN
ℹ ATTENTION	REFER TO LOCAL/NATIONAL CODES FOR PROPER INSTALLATION
⚡ POWER ON	FAILURE TO FOLLOW INSTALLATION INSTRUCTION MAY VOID THE WARRANTY
⏻ POWER OFF	DO NOT TOUCH LEDS. LEDS MUST BE PROTECTED FROM MECHANICAL STRESS OR DEBRIS
	TURN OFF POWER DURING INSTALLATION OR SERVICING









DRIVER SERVICING


1



2




2




LED SERVICING

1




DISCONNECT LED WIRES AND REMOVE LED INSERT

2




3




DRIVER SERVICING


1



2




2




LED SERVICING

1



DISCONNECT LED WIRES AND REMOVE LED INSERT

2



3

